


DENVER WCT-8020W . How to pair remote for Wi-Fi

On the camera itself, push once on the small button when you are in TEST mode. Then the red diode to the right will light up constantly. Now push a button on the remote, and then the diode will turn off the light. Now the remote are paired.





Then put the camera in ON mode (takes approximately 10 seconds).. Make sure nothing is moving in front of the camera (because if motion sensor is active, then the wi-fi/remote doesn't work). Push the ON button on the remote.. The camera will blink red a couple of times and then become blue.

Now the camera is in WI-FI mode.

To turn Wi-Fi off, push the OFF button on the remote. You might want to do it a couple of times. Then the camera will blink red and goes back to motion sensor mode.

